

TABLE 3 - CONVERSION CHART FOR BDT  
 < 50 Pa

If the maximum pressure achievable, in Pascals, is:	Then multiply the test cfm by the CRF factor below to value below to calculate the equivalent cfm50
25	1.62
26	1.58
27	1.54
28	1.5
29	1.46
30	1.43
31	1.4
32	1.37
33	1.34
34	1.31
35	1.28
36	1.26
37	1.23
38	1.21
39	1.19
40	1.17
41	1.15
42	1.13
44	1.09
45	1.08
46	1.06
47	1.04
48	1.03
49	1.01